



Warwick Road  
Fairfield Industrial Estate  
LOUTH  
Lincolnshire LN11 0YB

Telephone: (01507) 608100  
Fax: (01507) 608090  
email: enquiries@pozzani.co.uk  
www.pozzani.co.uk  
Registered in England No. 2215909

### **Tap Adjustment Instructions**

Firstly turn off the system's water supply, then remove the spout from the tap base. This can normally be done by pulling firmly upwards as the spouts are held in by 2 small O rings. (There are a small number of taps that have screw-in spouts, but yours is unlikely to be one of those)

With the spout removed, push the tap lever back over the hole that the spout left behind. The lever should detach itself and will reveal a small brass T-shaped adjuster.

As the tap lever works in either direction it is trial and error as to which direction you need to turn the adjuster. We normally suggest giving it 1 turn, reassembling the tap and testing it to see if it is better or worse. If it is better it may need a little more adjustment in the same direction. If it is worse, then you need to turn it the opposite way.

To put the lever back on you must slide it onto the T-piece starting at the narrowest end of the lever - please see the diagram as the T-piece must be pointing in the right direction. You have to be quite firm with them sometimes and then it will just 'snap' back into place. The spout can be pushed back into place and the water turned back on.



- Remove spout
- Remove lever
- Turn T piece
- Replace lever
- Replace spout

Read photo description  
for step-by-step  
instructions.

Any problems, you can  
call us on  
01507 608 100